



## **CP 468 – Artificial Intelligence**

**Spring 2024**

**Group 12**

### **How to Download, Configure, Train, and Test Pre-Trained Models**

**Member 1 Name:** Laiba Ali

**ID:** 169021077

**Member 2 Name:** Aliha Ali

**ID:** 210184090

**Member 3 Name:** Arsalan Khan

**ID:** 210862640

**Member 4 Name:** Rhyme Her

**ID:** 20157720

**Submission Date:** August 2nd, 2024

**All the listed members have contributed, read, and approved this submission.**

**Member 1 Name:** Laiba Ali

**Signature:** Laiba.Ali

**Member 2 Name:** Aliha Ali

**Signature:** AA

**Member 3 Name:** Arsalan Khan

**Signature:** AK

**Member 4 Name:** Rhyme Her

**Signature:** RH

# Introduction

This document serves as a guide for downloading, configuring, training, and testing pre-trained models for lung cancer detection from CT images using Google Colab.

## Steps Overview:

1. **Setup and Installation**
2. **Data Loading and Preprocessing**
3. **Model Training (Simple CNN, VGG16, ResNet50, InceptionV3)**
4. **Gradio Interface Setup**
5. **Evaluation and Reporting**

# Step-by-Step Instructions

## 1. Setup and Installation

**Objective:** Ensure all necessary libraries and tools are installed.

**Action:**

- Open Google Colab.
- Run the setup and installation code to install required libraries such as pydicom, gradio, pillow, tensorflow, matplotlib, cv2, numpy, sklearn, PIL, os, google.colab, and ImageDataGenerator from tensorflow.keras.

## 2. Data Loading and Preprocessing

**Objective:** Download the dataset, connect Google Drive to Colab, and prepare the data.

**Action:**

1. **Download the Dataset:**
  - Obtain the dataset from [Kaggle](#) or [Google Drive](#).
2. **Connect Google Drive to Colab:**
  - Mount your Google Drive to access the dataset.
3. **Specify Data Paths:**
  - Define paths for training, validation, and testing data.
4. **Load and Preprocess Data:**
  - Use functions to load file paths and labels.
  - Convert images to RGB format and preprocess for each model type (resnet, inception, vgg).

## 3. Model Training

**Objective:** Train each model (Simple CNN, VGG16, ResNet50, InceptionV3).

**Simple CNN**

- **Data Augmentation:** Initialize with various transformations such as rotation, width/height shift, shear, zoom, horizontal/vertical flip, brightness variation, and fill mode.
- **Create Data Generators:** For training and validation.
- **Model Definition and Training:** Define a Sequential model with Conv2D, MaxPooling2D, Flatten, Dense, and Dropout layers. Compile and train the model with Adam optimizer, sparse categorical cross-entropy loss, and accuracy metrics.

**VGG16**

- **Data Generators:** Create for training and validation.
- **Model Definition and Training:** Use VGG16 as the base model, freeze it, add custom layers on top, compile with Adam optimizer, sparse categorical cross-entropy loss, and accuracy metrics. Train the model with early stopping.

### ResNet50

- **Data Generators:** Create for training and validation.
- **Model Definition and Training:** Use ResNet50 as the base model, freeze it, add custom layers on top, compile with Adam optimizer, sparse categorical cross-entropy loss, and accuracy metrics. Train the model with early stopping.

### InceptionV3

- **Data Generators:** Create for training and validation.
- **Model Definition and Training:** Use InceptionV3 as the base model, freeze it, add custom layers on top, compile with Adam optimizer, sparse categorical cross-entropy loss, and accuracy metrics. Train the model with early stopping.

## 4. Gradio Interface Setup

**Objective:** Set up a user-friendly interface for model predictions.

**Action:**

- Implement a Gradio interface that allows users to upload JPG or PNG files, processes the image using the ensemble of pre-trained models (VGG16, ResNet50, InceptionV3), and displays the predicted class and image preview.
- Customize the interface with a dark theme and project information.

## 5. Evaluation and Reporting

**Objective:** Evaluate the performance of each model and the ensemble.

**Action:**

- Implement evaluation functions to calculate test loss and accuracy, generate confusion matrices, and classification reports.
- Plot ROC curves for each class.
- Evaluate the Simple CNN, VGG16, ResNet50, InceptionV3, and the ensemble model using the test dataset.
- Display evaluation metrics and ROC curves.

## Summary

1. **Setup and Installation:** Install required libraries.
2. **Data Loading and Preprocessing:** Download dataset, connect Google Drive, and preprocess data.
3. **Model Training:** Train Simple CNN, VGG16, ResNet50, and InceptionV3 models.
4. **Gradio Interface Setup:** Implement a user-friendly interface for predictions.
5. **Evaluation and Reporting:** Evaluate models and ensemble performance using test data.